



www.siemens.com/buildingtechonologies

Cerberus ECO Fire Safety Products and Accessories Product Catalogue

siemens.com/buildingtechnologies

Contents

Cerberus ECO enjoy protecting	3
FC18 Control Panel Range	4
FD181 device range	5
Cerberus ECO System overview	6
Cerberus ECO at a glance	8
System Load Reference	9
Controller	10
FC1820 / FC1840 Fire Alarm Controller	10
FC1861 / FC1862 / FC1863 Fire Alarm Controller	10
Detectors and other field devices	12
FDO181 Smoke Detector FDO181/FDO181C Dust Cap (Red)	12 12
FDT181 Heat Detector	12
FDB181 Detector Base	13
FDO181C Collective Smoke Detector	14
FDT181C Collective Heat Detector	14
FDB181C Collective Detector Base	15
FDCAI181 Alarm indicator	16
FDM181 Manual Call Point	17
FDCIO181-1 Input Module	18
FDCIO181-1 Input/Output Module	18 19
FDClO181-2 Input/Output Module FDCl181-2 Input Module	20
FDCI183 Collective Input Module	20
FDCL181 Line Separator	20
FT1810 Floor Repeater Display	22
Mimic Display Board	22
Spare Parts	26
FCM1811-A1 FC18 CPU Board (For FC1820/40/6x)	23
FCM1820-A1 FC18 Interlocking Board (For FC1820/40/6x)	23
FCI1801-A1 FC18 Line Card (For FC1820/40)	24
Housing for FC18 Series Module	24
FCI1802-A1 BDS Line Card for FC18 Controller	25
FCI1802-B1 BDS Line Card for FC18R Controller	25
FC18 Printer (For FC1820/40/6x)	26
FHA1810-A1 FC18 Housing Front Cover (For FC1820/40)	26
FCM1821-A1 FC18 Terminal Board (For FC1820/40)	26
FCA1804 FC18 USB/RS232 Adapter FC18 Power Supply (5A) (Power supply for FC1820/40)	27 27
FC18R-FC186x Line card (For FC186x)	27
FC18R-FC186x Terminal Board of Main board (For FC186x)	28
FC18R-FC186x Terminal Board of Interlocking Panel (For FC186x)	28
FC18R-FC186x Terminal Board of Line card (For FC186x)	28
FC18R Power Supply (Power supply for FC186x)	28
FC18R-FC186x Main Unit (For FC186x)	28
Order No. Index	29
Appendix	31
Appendix Index	31
System Installation Guidelines	32
	41

Cerberus ECO enjoy protecting

Lives and businesses deserve reliable protection from the risk of fire, and in Siemens' Cerberus ECO you can benefit from such protection by the system's exceptionally smart and powerful fire detection product series. Cerberus ECO has specifically been designed with small to medium premises in mind - including commercial buildings, hotels, shopping arcades, residential and a host of similar enterprises.

With more than 160 years of Siemens fire safety expertise to draw upon, Cerberus ECO incorporates key state-of-the-art global technologies that are second to none. The products and system adopt simple maintenance and operation design concepts in order to keep installation and commissioning as straightforward as possible. Cerberus ECO delivers dependable fire detection and alarm signalling, while maximising the protection of individuals, buildings and assets.

Designed for simple installation, maintenance and operation (SIMO design concept)

Tailored for the needs of users in small to medium sized businesses for simple, cost-efficient protection, Cerberus ECO has adopted simple installation, maintenance and operation design concepts for the products and system that take into account the complete working cycle of installers and users.

International quality product

Cerberus ECO has been specially developed by a dedicated SMART R&D team based in China, a strong centre of competency for SMART products (Simple, Maintenance-friendly, Affordable, Reliable, Timely-to-market). This ECO product series incorporates key state-of-the-art global technologies and system architecture, while complying with Siemens' high quality standards.

Complete product range - A wide range of applications

Cerberus ECO's compact and complete range of cost-efficient fire safety products - tailor-made to protect your staff, buildings and assets - comprises fire detectors as well as control panels and peripheral equipment such as manual call points, and input and output modules. Cerberus ECO is the reliable choice for a wide range of applications whether they are for commercial buildings, hotels, shopping arcades, commercial, residential or similar enterprises.

Putting you first

- Service is part of the package

Siemens recognises that pre-sales and after-sales services are essential for reliable fire detection products, which is why Cerberus ECO comes with a series of valuable service offerings for both installers and users. To support users to effortlessly install and operate the system, Siemens offers a customer hotline, e-training, and quick and reliable logistics.

Powerful networking

Cerberus ECO installation grows with you. So should you want to extend or convert your building, Cerberus ECO installation can be easily expanded.

Free wiring topology

Cerberus ECO enables you to achieve higher cost-effectiveness by optimising installation and maintenance costs via free wiring topology.

Smart devices

- Innovative features

Devices in the Cerberus ECO product series are equipped with numerous powerful features for easy installation and commissioning. The dust and dirt compensation feature and 'Sticker method' installation for detectors, 360-degree viewable alarm indicator, PCfree commissioning on panel with large easy-to-read LCD monitor, and easy-touse menu button on panel, are just some of the innovative features of this system.

Highlights

- Reliable product incorporates key state-of-theart global technologies and Siemens' high quality standards
- High cost-effectiveness affordable by small to medium sized businesses
- Smart design for simple installation, maintenance and operation
- User-friendly operation expandable and compatible with future developments



FC18 Control Panel Range

Highlights

- Highly user-friendly panel range with three panel options.
- Quick and accurate programming via PC or on panel with large 320 x 240 pixels LCD monitor.
- Easy-to-use menu button to call out pull-down menu for swift testing, commissioning, configuration, event management, monitoring and report handling.
- Flexible file handling simplifies commissioning and reduces costs.
- Easy programming and commissioning enabled by innovative tools and functions.

Highly user-friendly panel range

A new range of control panels (FC18) with three panel options - FC1820 (\leq 252 points), FC1840 (\leq 504 points) and FC186x (504 - 1,512 points) - are offered in the highly user-friendly Cerberus ECO product series, which makes installation, operation, integration and maintenance easier than ever.

Cerberus ECO provides the flexibility you need for system expansion, modernisation and backward-compatibility innovation, and enables you to achieve higher cost-effectiveness by optimising installation and maintenance costs with flexible wiring technology. This new panel stubs on loop as well as star style field bus topology and free polarity wire connection. Each panel can monitor and operate from 252 to 1,512 devices and enables networking with up to 32 panels.

Programming - PC or Panel

The Cerberus ECO FC18 control panel range supports programming via PC or panel. Equipped with a large 320 x 240 pixels LCD monitor, programming work is rapid and accurate.

Easy-to-use - Menu button on panel

An easy-to-use menu button is available on the FC18 control panel range. Testing, commissioning, configuration, event management, monitoring and report handling are all easily accomplished by simply pushing the menu button to call out the user-friendly pull-down menu.

Flexibility - File handling

Cerberus ECO incorporates a series of features to support flexible file handling to reduce commissioning costs:

- Configuration file can be exported to and imported from Excel file.
- No re-configuration / re-download of configuration file necessary following firmware version updates.
- 'Download & Upload priority' enables uninterrupted download and upload process.
- History record can be uploaded from panel to PC to accommodate 'Expandable archiving'.
- 'Customer report' file with information on all devices mounted on site can be exported.

Easy programming and commissioning Innovative tools and functions to simplify and reduce the time for programming work, such as:

- 'Unique ID code' for each peripheral enables easy localization and lifecycle identity.
- 'Logical expression name' to enhance readability.
- 'Group programming' function to simplify logic relations.
- 'Multi-device-select' function enables assignment of multiple devices in one group.
- 'System copy & paste' function for easy merging of configurations by different technicians.



FD181 device range

Complete range of devices

A complete range of devices (FD181) are offered in the Cerberus ECO fire detection product series, including smoke and heat detectors. Dual-channel input module and dual-channel input/output module with open/short circuit monitoring, floor repeat terminal for easy access of alarm information, re-settable manual call point, collective input module, and an isolator module are also provided as part of the comprehensive package.

Fast & Accurate fire detection

Benefit from Siemens advanced communication protocol from global R&D team, which assures quick identifying of fire dangers and reliable signal transmission.

Logical 'Sticker method' installation

The detectors are designed for easy commissioning by logical 'Sticker method' installation. Each detector has a unique device ID sticker attached at the back that can be positioned on project drawings for quick and accurate testing and commissioning.

Protective caps and dust/dirt compensation

Eye-catching protective cap in red is available for the protection of smoke detector during the installation period. Together with a dust/dirt compensation feature, greatly facilitate smoother installation work and reduce costs.

Strict enforcement of environmental standard

In deference to the environment, all detectors are RoHS compliance.

Highlights

- Advanced communication protocol assures fast & accurate fire detection
- Complete range of devices with smart designs
- Logical 'Sticker method' installation via unique device ID sticker
- Detector protective caps and dust compensation feature facilitate smoother installation and reduce costs

Cerberus ECO System overview

Powerful control panels, smart detectors and complete peripheral devices. Cerberus ECO fire detection product series supports powerful networking and provides a smart choice for reliable protection.

12

FC18-FC1840

Fire alarm controller







NAC circuit



Cerberus ECO at a glance

		U					
	Control panels						
Туре	FC1861 / FC1862 / F	C1863	1863 FC1840			FC1820	
Description	Fire alarm contro	oller	Fire alarm con	troller (504 points)	Fire al	arm contro	ller (252 points)
	Loop, stub on loop or star			plarity wire connection ammable from PC or		ocking up 1	to 8 panels, easy-
Features	2 loops / 4 loops / 6 504 devices / 1,008 devi devices		2 loops,	504 devices	1 loop, 252 devices		2 devices
			Dete	ctors			
Туре	FDO181	FD	T181	FDO181C			FDT181C
Description	Addressable Smoke detect (with protective red cap)		Addressable heat Collective smoke de		etector	Collecti	ve heat detector
Features	Easy commissioning by 'Sticker method' installatio with dust compensation	n, ['] Stickei	nissioning by r method' allation	Collective detector address setting, p free connection	oolarity address setting, polarity		setting, polarity
			Addressabl	e modules			
Туре	FDCI183	FDCI181-2	FDCIO181-	2 FDCL181	FDO	CI181-1	FDCIO181-1
Description	Collective Input Module	Input module	I/O module	e Line Separator	Inpu	t module	I/O module
Features	1 monitored inputs as collective detector connection	Dual-channel Input	Dual-chann Input/Outp				
	Resettable manual call point	Mimic Dis	Mimic Display Board		er	Alarr	n indicator
							-
Туре	FDM181	FTM	1811	FT1810		F	DCAI181
Description	Manual Call Point	Mimic Dis	play Board	Floor Repeater Dis	play	Alar	m indicator
Features	With reset function		its for LED ation			uickly the source alarm signal	

System Load Reference

Detectors and other field devices

Туре	Name	Load Factor	Quiescent current(mA)	Max. current(mA)
FDO181	Smoke Detector	1	0.26	1.20
FDT181	Heat Detector	1	0.26	1.20
FDO181C	Collective Smoke Detector	0	0.1	60
FDT181C	Collective Heat Detector	0	0.1	60
FDM181	Manual Call Point	1	0.22	1.20
FDCI181-2	Input Module	3	0.33	0.45
FDCI0181-2	Input/Output Module	5	0.56	0.85
FDCL181	Line Separator	1	0.25	0.43
FDCI183	Collective Input Module	3	0.45	1.1
FDCI181-1	Input module	3	0.27	0.37
FDCIO181-1	Input/Output module	3	0.31	0.51
FDCAI181	alarm indicator	1	0.2	—

Floor Panel

Туре	Name	Address	Quiescent current(mA)	Max. current(mA)
FT1810	Floor Repeater Display	1	30	110
FTM1811	Mimic Display Board	1	100	200

Panels

Туре	Name	Address	Quiescent current(A)	Max. current(A)
FC1820	Fire Alarm Controller (≤ 252 points)	1	0.55	2.00
FC1840	Fire Alarm Controller (≤ 504 points)	1	0.60	2.50
FC1861	Fire Alarm Controller (≤ 504 points)	1	0.75	2.50
FC1862	Fire Alarm Controller (≤ 1,008 points)	1	1.23	3.80
FC1863	Fire Alarm Controller (≤ 1,512 points)	1	1.71	5.20

Controller Controller

Туре			Order No.
FC1820	FC1820 / FC1840 Fire Alarm Con	troller	S54420-C1-A1
	preset time, LCD backlight will automatically turn	tems of equipment/event ds, first-in-first-out order; all or message to display within off. When there are events /	
FC1840	 LCD backlight Auto-off mode. When no operation or message to display within preset time, LCD backlight will automatically turn off. When there are events / operations, LCD will light up automatically to display events and/or interlock devices 2 channels of programmable input/output (Output: 40mA@24VDC can be programmed as general alarm output or general trouble output; Input: dry contact) 1 channel of NAC for audible and visible devices (max. 0.5A @24VDC) 8 channels of interlocking functions for automatic control and manual operations of control equipment Efficient group programming according to different usage FC1820 controller can connect up to 252 points; FC1840 controller can connect up to 504 points Up to 32 controllers can be networked together Max. distance of controller network bus (FC18-BUS) 1,000m Twisted paired cable for polarity-free detection bus (FD18-BUS); max. loop distance up to 2,500m, and max. stub distance up to 1,500m (wiring capacity from 1.0 to 1.5 mm²) Three user levels for different operation authority. Each user level accessed by pre-defined, changeable password Convenient pluggable terminals with clear marks for field wiring Auto-mapping function supports commissioning task Detection algorithm can be adjusted by controller according to different environment to provide high reliability of alarm report and reduce false alarms Programming either directly from controller or computer "Sticker Method" for ease of on-site commissioning FC18-BUS controller bus can be configurated as loop or stubs FC18-BUS controller bus can be configurated as loop or stubs FC18-BUS controller bus can be configurated as loop or stubs FC18-BUS controller bus can be configurated as loop or stubs FC18-BUS controller bus can be configurated as loop or stubs		S54420-C2-A1
	Maximum history records Max. distance between controllers within FC18-BUS Max. No. of controllers connected within FC18-BUS Max. distance between controller and FRT within FR18-BUS Max. No. of FRT connected to controller Auto-mapping function Battery (not included) Communication interface Input voltage Power supply capacity External power output Size (mm) Weight (without battery) Power fuse Battery fuse Operating temperature Storage temperature Relative humidity Protection category Environment requirement Datasheet	10,000 1,000 m 32 1,000 m 32 Operation from terminal Depends on local regulation Special converter module 220VAC@1.5A, 110VAC@3A 220VAC/50Hz, 110VAC/60Hz 5 A@24 VDC 1 A@24 VDC 1 A@24 VDC 437Wx 408Hx170D 10.35 kg 220VAC@1.5A, 110VAC@3A 24 VDC@5.0 A 0 ~ +40 °C -10 ~ +50 °C \leq 95% (40±2°C) IP30 Indoor / Clean A6V10322968	

Controller Controller



Detectors and Base

Туре			Order No.
FDO181	FDO181 Smoke Detector		S54320-F2-A1
	 The FDO181 wide-spectrum smoke detector is an optical smoke detector with an optical sensor. It works according to the principle of forward scattering. The detector reacts extremely sensitively to light aerosols caused by fire. The increased sensitivity makes possible the early detection of smouldering and open fires. With built-in CPU, signals received are processed by intelligent algorithm Two kinds of sensitivity settings (standard, sensitive) Opto-electronic sampling chamber more reliably and accurately detects fire Automatically addresses setting without encoder setting or DIP switch For early detection of smoke and smouldering fires Resistant to environment and interference factors such as dust, fibres, insects, humidity, extreme temperatures, electro-magnetic interference, corrosion, vapour, vibration, synthetic aerosols and atypical fire phenomena All-around visible alarm indicator Communication via FD18-BUS, polarity-free connection "Sticker Method" for ease of commissioning 		
	Operating voltage Operating current (quiescent) Activation current Sensitivity Operating temperature Storage temperature Relative humidity Communication protocol Load factor Colour Protection category GB4208-93	12 32 VDC 0.26 mA 1.2 mA Standard 2.5% Sensitive1.8% -10 +50°C -20 +75°C ≤96% (40±2°C) FD18-BUS 1 White, RAL 9010 IP44	
	Datasheet	A6V10326259	
FDO181_DC	FDO181/FDO181C Dust Ca	p (Red)	
	Protects the FDO181 smoke detector and FDO the installation. (Please remove the dust cap after installation		

Detectors and Base



Туре			Order No.
FDT181	FDT181 Heat Detecto	r	S54320-F3-A1
SIEMENS	Heat detector FDT181 is an intellig inside a building.	ent detector. It is used for early fire detec	ction
	 Two operation modes: A2S/A2R Automatically addresses setting v All-around visible alarm indicator 	erference factors such as humidity, electro-r vibration. Jlarity-free connection	mag-
	Operating voltage Operating current (quiescent) Activation current Operating temperature Storage temperature Relative humidity Communication protocol Load factor Colour Protection category GB4208-93 Datasheet	12 32 VDC 0.26 mA 1.2 mA -10 +50 °C -20 +75 °C ≤96% (40±2°C) FD18-BUS 1 White, RAL 9010 IP44 A6V10326261	
-DB181	FDB181 Detector Bas	e	S54320-F1-A1
	used for the installation of FD181 se • FDO181 Smoke detector • FDT181 Heat detector	h surface install and conceal install se for easy cable insertion	e and
	Connection terminals Operating temperature Storage temperature Protection category GB4208-93 Colour	1.0 1.5 mm ² According to data of detectors White, RAL 9010	
	Datasheet	A6V10326265	

Detector and Base

Туре			Order No.
FDO181C	FDO181C Collective	Smoke Detector	S54320-F11-A2
SIEMERS	ing to the principle of forward sc	detector with an optical sensor. It works accord- attering. The detector reacts extremely sensitive The increased sensitivity makes the detection of	
	 gence for optimum reliable det Opto-electronic sampling cham Collective detector, no address Communication with FC18 con FDCI183 can connect max. 32 of Particularly suited for the ear smoldering fires Resistant to environment and humidity, extreme temperatur sols. With immunity against ele Self-test of operating status, w tor can prompt user Automatic drift compensation a of dust accumulation 360° visible alarm indicator 	aber detects fire more reliable and accurate setting, polarity free connection troller via FDCI183 collective input module, each collective detectors rly detection of smoke-generating flaming and interference factors such as dust, fibers, insects, res, corrosive, vapors, vibration, synthetic aero-	
	Colour Protection category GB4208-93	White, RAL 9010 IP40	
FDT181C	FDT181C Collective	A6V10361096 Heat Detector	S54320-F12-A2
SILMERS	 inside a building. Operation modes: A2 Collective detector, no address Communication with FC18 con FDCI183 can connect max. 32 360° visible alarm indicator Resistant to environment and 	collective detector. It is used for fire detection setting, polarity free connection troller via FDCI183 collective input module, each collective detectors interference factors such as humidity, corrosive gainst electro-magnetic interference.	
	Operating voltage Operating current (quiescent) Activation current Operating temperature Storage temperature Relative humidity Colour Protection category GB4208-93 Datasheet	10 28 VDC 0.1 mA 60.0 mA −10 +50 °C −20 +70 °C ≤96% (40±2°C) White, RAL 9010 IP40 A6V10361100	

Detector and Base



a base		
		Order No.
FDB181C Collective Detector Base		S54320-F9-A2
 tion site and are used for installations FDO181C collective smoke detector FDT181C collective heat detector Universal bases, applicable to both Large opening in the detector base 		
Connecting terminals Operating temperature Storage temperature Protection category GB4208-93 Colour	1.0 1.5 mm ² According to data of detectors White, RAL 9010	
Datasheet	A6V10361102	
	FDB181C Collective D The FDB181C collective detector bas tion site and are used for installation • FDO181C collective smoke detector • FDT181C collective heat detector • Universal bases, applicable to bott • Large opening in the detector bas • Adopt environmentally friendly m Connecting terminals Operating temperature Storage temperature Protection category GB4208-93 Colour	FDB181C collective detector bases are universal bases. It's fixed on fire detector ion site and are used for installations of FD181C series collective detectors: • FD0181C collective smoke detector • FD0181C collective heat detector • Duriversal bases, applicable to both surface install and conceal install • Large opening in the detector base for easy cable insertion • Adopt environmentally friendly materials Connecting terminals Operating temperature Storage temperature Protection category GB4208-93 Colour 1.0 1.5 mm ² According to data of detectors White, RAL 9010

Alarm Indicator

Туре			Order No.
FDCAI181	FDCAI181 Alarm indi	cator	
	The FDCAI181 alarm indicator is connected to the loop and can be programmed to indicate quickly the source of an alarm signal from detectors which are not easily accessible or visible. Addressing and control takes place via the control panel. The alarm indicator is switched as if it was a detector in the detector line. The alarm indicator has 2x2 connectors for the detector line. The alarm indicator contains indicator lamps (LEDs). They light up as soon as the connected fire detector gives an alarm.		S54370-F21-A1
	 Addressable external alarm indica Indication of detectors in alarm in Free programmable Communication via FD18-BUS (in Modern flat design Non screw terminals Ecologically processing Recyclable materials Electronic and synthetic material 	n ceiling voids etc. ndividual addressing)	
	Operating voltage Operating current (quiescent) Blinking cycle Load factor Connection terminals Operating temperature Storage temperature Humidity Communication protocol Color Protection category	DC 12 33 V <200µA 1s: Locate or Alarm 0.5s: Locate when Alarm 1 1.01.5 mm 2 -10 +55 °C -20 +70 °C ≤95 % rel FD18-BUS white, ~RAL 9010 IP40	
	Datasheet	A6V10384005	





Туре			Order No.
FDM181	FDM181 Manual Call	Point	S54321-F1-A1
(A	The manual call point serves for the consists of a housing and an electron	e manual activation of alarms in case of fire. It nic component.	
	Resettable operation panel		
Lines.	 Automatically address setting wit Indicates condition (Alarm or Location) Communication via FD18-BUS 	 Automatically address setting without encoder setting or Dip-switch Indicates condition (Alarm or Locate) by means of an LED 	
		12 221/26	
	Operating voltage Operating current (quiescent)	12 32 VDC 0.22 mA	
	Activation current	1.2 mA	
	Operating temperature Storage temperature	−10 +50 °C −20 +75 °C	
	Relative humidity	≤95%	
	Communication protocol	FD18-BUS	
	Load factors Connection terminals	1 1.0 1.5 mm²	
	Colour	Red, RAL3000	
	Protection category GB4208-93	IP44	
	Datasheet	A6V10326263	

Туре			Order No.
FDCIO181-1	FDCIO181-1 Input Mc	odule	S54322-F7-A1
	is man-datory) Microprocessor-controlled signal Prevention of noise interference LED display of input status Automatic address setting, witho Power supply via FD18-BUS Communication with controller v Directly used in dry areas, Applic FDCH221 housing "Sticker Method" easy for commis	through intelligent analysis of input signals ut encoder settings or Dip-switch ia FD18-BUS(detection line) able in dusty and humid areas when installed in sioning	
	Operating voltage Operating current(Quiescent) Activation current Monitoring resistors Operating temperature Storage temperature Humidity Communication protocol Load factors Connection terminals Color - Housing - Cover Protection category EN60529/IEC529/GB4 - With housing FDCH221 Datasheet	12 32 VDC 0.27 mA 0.37 mA 3.3KΩ(1/4w) / 680Ω(1/4w) 0 +42 °C −20 +75 °C ≤95 % FD18-BUS 3 1.0 1.5 mm ² white, RAL 9010 transparent i208-93 IP65 A6V10436763	
FDCIO181-1	FDCIO181-1 Input/Ou		S54322-F8-A1
SUMAL : The Market Control of the Market Co	 Microprocessor-controlled signal evaluation Automatic address setting, without encoder settings or DIP switch 1 monitored input, 1 monitored output LED display of input and output status Input lines monitored for open line or short/open circuit Prevention of noise interference through intelligent analysis of input signals Output lines monitored for open line or short/open circuit (when potential output not acti-vated) Output monitoring configurable(on/off) Control output for equipment 24 VDC, max. 2 A Communication with controller via FD18-BUS(detector line) Directly used in dry areas. Applicable in dusty and humid areas when installed in FDCH221 housing "Sticker Method" easy for commissioning 		
	Operating voltage Operating current (quiescent) Activation current Output - Capacity - Monitoring resistor - Diode Input - Monitoring resistor Operating temperature Storage temperature Humidity Communication protocol Load factors Connection terminals Color - Housing - Cover Protection category EN60529/IEC529/GB4 - With FDCH221 housing Datasheet	12 32 VDC 0.31 mA 0.51 mA 2 A @ 24 VDC 3.3k $\Omega(1/4w)$ 1N5404 3.3k $\Omega / 680 \Omega$ 0 +42 °C -20 +75 °C $\leq 95 \%$ rel. FD18-BUS 3 1.0 1.5 mm ² white, RAL 9010 transparent 1208-93 IP65 A6V10436766	



Туре			Order No.
FDCI0181-2	FDCIO181-2 Input/Output Module		S54322-F2-A1
	 2 monitored inputs, 2 monitore LED display of input and outpu Input lines monitored for open mandatory) Prevention of noise interference Output lines monitored for op put not activated) Output monitoring configurable Control output for equipment 2 Communication with controlled 	nout encoder settings or DIP switch ed outputs t status line or short/ open ciruit(terminal resistors e via intelligent analysis of input signals en line or short/open circuit (when potential out- e(on/off) 24 VDC, max. 2 A r via FD18-BUS(detector line) licable in dusty and humid areas when installed in	

Туре			Order No.
FDCI181-2	FDCI181-2 Input Module		S54322-F1-A1
	 2 monitored digital inputs Input lines are monitored for open line or short/open circuit (terminal resistors mandatory) Microprocessor-controlled signal evaluation Prevention of noise interference via intelligent analysis of input signals LED display of input status Automatic address setting, without encoder settings or Dip-switch Power supply via FD18-BUS Communication with controller via FD18-BUS (detection line) Directly used in dry areas. Applicable in dusty and humid areas when installed in FDCH221 housing "Sticker Method" for ease of commissioning 		
	Operating voltage Operating current (quiescent) Activation current Monitoring resistors Operating temperature Storage temperature Relative humidity Communication protocol Load factors Connection terminals Colour - Housing - Cover Protection category EN60529 / IEC529/GB4208-93 With FDCH221 housing Datasheet	12 32 VDC 0.33 mA 0.45 mA 3.3k Ω (1/4w) / 680Ω(1/4w) 0 +42 °C -20 +75 °C ≤95 % FD18-BUS 3 1.0 1.5 mm ² white, RAL 9010 transparent IP65 A6V10326257	
FDCI183	FDCI183 Collective Input	Module	S54312-F8-A2
	 1 monitored input as collective detector LED display of alarm and fault status External 24VDC power required Microprocessor-controlled signal evaluat Earth fault monitoring With the Zener diode barrier, it is als detectors Directly used in dry areas.Applicable in or FDCH221 housing "Sticker Method" for ease of commission 	ion o possible to connect intrinsically safe lusty and humid areas when installed in	
	FD18-BUS Operating voltage FD18-BUS Operating current	12 33 VDC Quiescent: 0.45mA Alarm:1.1mA	
	External power supply - Input voltage End of line Operating temperature Storage temperature Relative humidity Communication protocol Local factors Connection terminals Color - Housing - Cover Protection category EN60529 / IEC529 - with FDCH221 housing Line impedance of collective detection line Datasheet	18 32 VDC @ 0.15A 1.5KE20CA(EOL) or EOL22(ex) -10 +50 °C -30 +70 °C ≤95 % FD18-BUS 3 1.0 1.5 mm ² Pure white, RAL 9010 transparen IP65 <150Ω (twins cable) A6V10362122	

Detectors and other field devices Module and Fire Repeater Display



Туре			Order No.
FDCL181	FDCL181 Line Separa	ator	S54322-F3-A1
		o detect and isolate the short-circuit part of the revent different branches from breaking down at	
	 Protection of FD18-BUS from short-circuit For T branches of FD18-BUS Indicates conditions by LED indicator Automatic address setting without encoder settings or Dip-switch Communication via FD18-BUS (separate address) Directly applicable in dry areas. Applicable in humid and dusty areas with FDCH221 housing "Sticker Method" for ease of commissioning 		
	Operating voltage	12 32 VDC	
	Operating current (quiescent) Activation current	0.25 mA	
	Operating temperature	0.45 mA 0 +42 °C	
	Storage temperature	−20 +75 °C	
	Relative humidity	≤95%	
	Communication protocol	FD18-BUS	
	Load factors	1	
	Connection terminals	1.0 1.5 mm ²	
	Colour		
	- Housing	white, RAL 9010	
	- Cover	transparent	
	Protection category EN60529 / IEC529/GB4208-93		
	With FDCH221 housing	IP65	
	Datasheet	A6V10326269	

Туре			Order No.
FT1810	FT1810 Floor Repeate	r Display	S54420-F3-A1
	The floor repeater display is an indica system with following functions:	tion and operation unit in a fire detection	
4-4-4=		on olling through lists itch off buzzer	
	 FC18 fire detection system Large backlight LCD display(192X6 Communication with controller via External 24VDC power required 	nd display panels for use with the addressed 4 pixels) whose contrast can be set manually 4 FR18-BUS (individual address) 9 plays can be connected to one FC18 fire alarm	
	Operating voltage Operating current (quiescent) Activation current Operating temperature Storage temperature Relative humidity Communication protocol Connection terminals Colour Protection category GB4208-93	24 VDC±20% 30 mA 110 mA 0 +42 °C -20 +60 °C ≤95 % FR18-BUS 1.0 1.5 mm ² white, RAL 9010 IP30	
	Datasheet	A6V10323189	
FTM1811	Mimic Display Board		S54420-F4-A1
	 60 outputs for LED activation 1 dry contact output for buzzer 2 inputs for "Buzzer silence" and "L Communication with controller via External 24VDC power required Input/output are not monitored 	amp test" I FR18-BUS(CAN-Bus) (individual address)	
	Operating voltage Operating current (quiescent) Max. current Rated output per LED Max. current per LED Operating temperature Storage temperature Relative humidity Communication Protocol Connection terminals	24 VDC±30% 100 mA 200 mA 10 mA 15 mA −3 +42 °C −20 +60 °C ≤95 % FR18-BUS 1.0 1.5 mm ²	
	Datasheet	A6V10260209	

Detectors and other field devices Cerberus ECO Controller Spare Parts



Cerberus LC	o controller spare raits		
Туре			Order No.
FCM1811-A1	FCM1811-A1 FC18 CPU Board (For FC1820/40/6x)		S54420-A12-A1
	 CPU board together with main board comprises main pa troller. Integration of some common components makes used for storing and loading configuration files. 		
	Datasheet A6V10244852		
FCM1820-A1	FCM1820-A1 FC18 Interlocking Bo	ard	S54420-A13-A1
	(For FC1820/40/6x)	and and manual and	
	 FCM1820-A1 interlocking panel mainly used for auto-c trol of important devices (such as fire-pump, fan, etc.) FCM1820-A1interlocking panel has 8 outputs, rated 24 vate extinguishing devices on-site; 8 dry contact inputs mation of activated devices 	VDC/ 40mA, use to acti-	
	Datasheet A6V10244854		

Detectors and other field devices Cerberus ECO Controller Spare Parts

Туре			Order No.
FCI1801-A1	 FCI1801-A1 FC18 Line Card (For FC1820/40) FCI1801-A1 line card specially designed for automatically identify controllers. Used for co devices FCI1801-A 1 line card contains 1 loop or 2 stu FCI1801-A 1 line card applies 2-wire polarity-field bus and free branch acceptable Overload protection available When short line occurs, will activate line pro When trouble resolved, line card recovers auto Datasheet 	onnection with FD181 series field bs, can connect 252 points free detection bus; stub wiring for tection application automatically.	S54420-A9-A1
FDCH221	Color wh	ies module ts M20 are not included 7 x 119 x 48mm ite, RAL 9010 / nsparent matt	S54312-F3-A1

Detectors and other field devices Cerberus ECO Controller Spare Parts



2

Order No. Type FCI1802-A1 S54420-A25-A1 FCI1802-A1 BDS Line Card for FC18 Controller <u>.</u> • FCI1802-A1 line card is specially designed for FC18 series controllers. It can be automatically identified by controller. It is used for connection with BC80 series field devices. FCI1802-A1 line card contains two lines and each line can connect 127 points. Compatible with BC80en, BC80-UL, FD180 series field deviecs. Compatible with BDS331 floor repeater display. • 2-wire polarity-free of detection bus, stub wring is available and free branch is acceptable. Operating voltage +28 V 650 mA / 24 V Quiescent current 1.1 A / 24 V Max. current Operating temperature 0 ~ +40 °C Storage temperature -10 ~ +50 °C Humidity ≤ 95% (40±2 °C) 110*120 mm Size Max. No. of line 2 Max. No. of field devices per line 127 Wire type for FD18-BUS Recommend RVS1.0 ~ RVS1.5 Line impedance ≤ 20 Ω Short circuit auto protection (isolation) available Datasheet A6V10412606 FCI1802-B1 FCI1802-B1 BDS S54420-A26-A1 Line Card for FC18R Controller • FCI1802-B1 line card is specially designed for FC18R series controllers. It can be

- FCI1802-B1 line card is specially designed for FC18R series controllers. It can be automatically identified by controller. It is used for connection with BC80 series field devices.
- FCI1802-B1 line card contains two lines and each line can connect 127 points.
- Compatible with BC80en, BC80-UL, FD180 series field devices.
- Compatible with BDS331 floor repeater display.
- 2-wire polarity-free of detection bus, stub wring is available and free branch is acceptable.

operating voltage
Quiescent current
Max. current
Operating temperature
Storage temperature
Humidity
Size
Max. No. of line for each card
Max. No. of field devices for each line
Wire type for FD18-BUS
Line impedance
Short circuit auto protection (isolation)
Datasheet

+28 V 650 mA / 24 V 1.1 A / 24 V 0 ~ +40 °C -10 ~ +50 °C ≤95% (40 \pm 2 °C) 155*120mm 2 127 Recommend RVS1.0~RVS1.5 ≤ 20 Ω available A6V10412608

Spare Parts Cerberus ECO Controller Spare Parts

Туре		Order No.
FCP1810-A2	FC18 Printer (For FC1820/40/6x) • Printer can print out history event or on real time	S54420-C18-A1
FHA1810-A1	FHA1810-A1 FC18 Housing Front Cover (For FC1820/40) • For cover of FC1820/40 fire alarm controller Datasheet A6V10244860	S54420-B19-A1
FCM1821-A1	FCM1821-A1 FC18 Terminal Board (For FC1820/40) • FCM1821-A1 terminal board specially designed for FC18 series controllers; easy for connection Datasheet A6V10244862	S54420-A14-A1

Spare Parts Cerberus ECO Controller Spare Parts



Cerberus LCO	Controller Spare Parts		
Туре			Order No.
FCA1804	FCA1804 FC18 USB/RS232 • For downloading and uploading firmware		S54420-F8-A1
FP1802-A2	FC18 Power Supply (5A) (Power supply for FC1820) Input voltage Output voltage Operating temperature Storage temperature Relative Humidity	/40) 220VAC/50Hz, 110VAC/60Hz 5 A@24 VDC -20 ~ +55 °C -45 ~ +85 °C ≤95%	S54420-C21-A1
FCI1802-A2	 FC18R-FC186x Line card (For FC186x) FC1802-A2 line card is specially designed cally identify controllers. It is used for controllers. It is used for controllers. It is used for control points FC1802-A2 line card contains 1 loop or a points FC1802-A2 line card apply 2-wire polar field bus and free branch is acceptable Overload protection is available When short line occurs, it will activate th matically. When trouble is resolved, line or Datasheet 	nnection with FD18 field devices 2 stubs, and each line can connect 252 ity-free detection bus, stub wiring for e line protection application auto-	S54420-A10-A1



Cerberus ECO Controller Spare Parts

Туре			Order No.
FCM1821-A2	FC18R-FC186x		S54420-A15-A1
Contraction of the local division of the loc	Terminal Board of	Main board (For FC186x)	
And the second sec	 FC18R-FC186x terminal boa for FC18R Main board, easy 	rd of Main board is specially designed for connection	
	Datasheet	A6V10322577	
FCM1822-A2	FC18R-FC186x		
		Interlocking Panel	S54420-A16-A1
	(For FC186x)	5	
		rd of Interlocking Panel is specially king panel, easy for connection	
	Datasheet	A6V10322579	
FCM1823-A2	FC18R-FC186x		S54420-A17-A1
		Line card (For FC186x)	
and the second second second			
- Marcel a	 FCM1823-A2 FC18R-FC186x terminal board of Line card is specially designed for FC18R Line card, easy for connection 		
	Datasheet	A6V10322581	
FP1801-A2	FC18R Power Supp	blv	S54420-C20-A1
	(Power supply for	-	
	Input voltage Output voltage Operating temperature Storage temperature Relative Humidity	220VAC/50Hz, 110VAC/60Hz 10 A@24 VDC -20 ~ +55 °C -45 ~ +85 °C ≤95%	
	Datasheet	A6V10322583	
FCM1801-A2	FC18R-FC186x Ma	in Unit (For FC186x)	S54420-C11-A1
	 Used for data collection and FCM1801-A2 FC18R-FC186> 	ard, interlocking panel, LCD and keypad analysis, and control the field device Main unit is used for operation, I kinds of events on LCD or front panel	
	Datasheet	A6V10322585	

Туре	Name	Order No.	Page	
FC1820	Fire Alarm Controller (252 points)	S54420-C1-A1	10	
FC1840	Fire Alarm Controller (504 points)	S54420-C2-A1	10	
FC1861 (504)		S54420-C5-A1		
FC1862 (1,008)	Fire Alarm Controller	S54420-C6-A1	11	
FC1863 (1,512)		S54420-C7-A1		
FDO181	Smoke Detector	S54320-F2-A1	12	
FDT181	Heat Detector	S54320-F3-A1	13	
FDB181	Detector Base	S54320-F1-A1	13	
FDO181C	Collective Smoke Detector	S54320-F11-A2	14	
FDT181C	Collective Heat Detector	S54320-F12-A2	14	
FDB181C	Collective Detector Base	S54320-F9-A2	15	
FDCAI181	Alarm Indicator	S54370-F21-A1	15	
FDM181	Manual Call Point	S54321-F1-A1	16	
FDCIO181-1	Input Module	S54322-F7-A1	17	
FDCIO181-1	Input/Output Module	S54322-F8-A1	17	
FDCIO181-2	Input/Output Module	S54322-F2-A1	18	
FDCI181-2	Input Module	S54322-F1-A1	19	
FDCI183	Collective Input Module	S54312-F8-A2	19	
FDCL181	Line Separator	S54322-F3-A1	20	
FT1810	Floor Repeater Display	S54420-F3-A1	21	
FTM1811	Mimic Display Board	S54420-F4-A1	21	
FCM1811-A1	FC18 CPU Board	S54420-A12-A1	22	
FCM1820-A1	FC18 Interlocking Board	S54420-A13-A1	22	
FCI1801-A1	FC18 Line Card	S54420-A9-A1	22	
FDCH221	Housing for FC18 Series Module	S54312-F3-A1	22	
FCI1802-A1	BDS Line Card for FC18 Controller	S54312-F3-A1	23	
FCI1802-B1	BDS Line Card for FC18R Controller	S54420-A25-A1	23	
FCP1810-A2	FC18 Printer	S54420-C18-A1	24	
FHA1810-A1	FC18 Front Cover	S54420-B19-A1	24	
FCM1821-A1	FC18 Terminal Board	S54420-A14-A1	24	
FCA1804	FCA1804 FC18 USB/RS232 Adapter	S54420-F8-A1	24	
FP1802-A2	FC18 Power Supply (5A)	S54420-C21-A1	24	
FCI1802-A2	FC18R-FC186x Line card	S54420-A10-A1	24	
FCM1821-A2	FC18R-FC186x Terminal Board of Main board	S54420-A15-A1	25	
FCM1822-A2	FC18R-FC186x Terminal Board of Interlocking panel	S54420-A16-A1	25	
FCM1823-A2	FC18R-FC186x Terminal Board of Line Card	S54420-A17-A1	25	
FP1801-A2	FC18R Power Supply	S54420-C20-A1	25	
FCM1801-A2	FC18R-FC186x Main Unit	S54420-C11-A1	25	





Cerberus ECO Fire Safety Products and Accessories Product Catalogue - Appendix

Appendix Index

System Installation Guidelines

System [Design Guidelines	32	
1.1	1.1 FC18-BUS		
1.2	FS18-BUS Controller Network	32	
1.3	Single controller capacity	32	
1.4	FC18/FC18R Controller Input/output wiring diagram	33	
1.5	FC18/FC18R Interlocking panel wiring diagram	33	
1.6	FC18/FC18R alarm device (NAC) wiring diagram	33	
1.7	1.7 System Wiring		
2.1	FR18-BUS	34	
2.2	FR18-BUS Floor Repeater Display (FRT) wiring diagram	34	
3.1	FD18-BUS	34	
3.2	FD18-BUS Line card diagram	34	
3.3	FD18-BUS Detection loop topology	35	
	3.3.1 Loop Topology	35	
	3.3.2 Stub Topology	35	
	3.3.3 Stub on loop topology	35	
	3.3.4 Line Separator application A	36	
	3.3.5 Line Separator application B	36	
	3.3.6 Line Separator application C	36	
	3.3.7 Line Separator application D	37	
	3.3.8 Line Separator application E	37	
	3.3.9 Line Separator application F	37	
Installati	ion and Wiring	38	
4.1	FDB181/FDB183 Detector Base Installation	38	

4.1	FDB181/FDB183 Detector Base Installation	38
4.2	FDB181C Collective Detector Base Installation	38
4.3	FDCAI181 Addressable Alarm Indicator Installation	39
4.4	FDCL181 Line Separator Installation	40
4.5	FDCI181-2 Input Module Installation	41
4.6	FDCIO181-2 Input/Output Module Installation	42
4.7	FDCI183 Collective Input Module Installation	43
4.8	FDM181 Manual Call Point Installation	44
4.9	FT1810 Floor Repeater Display Installation	45
4.10	FTM1811 Mimic Display Board Installation	46
4.11	FT1810 Floor Repeater Display Installation	47
4.12	FTM1811 Mimic Display Board Installation	48

28

Cerberus ECO System Installation Guidelines



In this section, we illustrate best practice for installation of fire detection equipment. While not all possible cases may be covered, these are intended to provide guidelines. Local regulations may be more detailed and must always be observed. Please contact your local Siemens sales organization for more detailed information and documentation.

Detectors should be positioned*

- at least 0.5 m from the wall
- max. 12 m from the previous detector

Manual call points manual call points should be positioned*

- in a clearly visible location
- 1.5 m from floor level



Fire control panels mounting the fire control panel*

Keep a minimum distance to objects which could obscure the panel or the view to it



Detector positioning near elevators*

Cerberus ECO System Installation Guidelines











Detector positioning near fresh air supply*

Use a support to install a detector at ceiling height*

Place the detector at the highest point in the room*

Cerberus ECO System Installation Guidelines



Ensure the correct distance to ceiling obstacles*



Position the detector within the top 10% of a space*



Ensure a minimum distance to objects which could obstruct the view to a manual call point*

Manual call points should not be obscured by an open door*

Cerberus ECO System Design Guidelines

1.1 FC18-BUS

Communication between controllers (CAN-BUS communication). Twisted-pair is required, the maximum length is 1,000m.

1.2 FC18-BUS Controller Network

- Cerberus ECO system enables max. connection of 32 Cerberus ECO controllers. Each controller can be configured to monitor and control all connected field devices within entire network.
- Interlocking controls can be programmed within the same controller or across other controllers.
- For FC18-Bus network will need to set the EOL through dip switch for the first and last controller.



1.3 Single controller capacity

Name	Туре	Build-in Line card	Max. line card	Max. loop	Max. Points
FC18-FC1820 Fire alarm controller	FC18-FC1820	1	1	1	252
FC18-FC1840 Fire alarm controller	FC18-FC1840	2	2	2	504
FC18R-FC1861 Fire alarm controller	FC18R-FC1861	2	*6	*6	504
FC18R-FC1862 Fire alarm controller	FC18R-FC1862	4	*6	*6	1,008
FC18R-FC1863 Fire alarm controller	FC18R-FC1863	6	*6	*6	1,512

* CPU can handle 8 line cards

Cerberus ECO System Design Guidelines

1.4 FC18/FC18R Controller Input/output wiring diagram

Note: the load range of each output is 24VDC, $600\Omega - 1.2k\Omega$



1.5 FC18/FC18R Interlocking panel wiring diagram

Note: the load range of each output is 24VDC, $600\Omega - 1.2k\Omega$



1.6 FC18/FC18R alarm device (NAC) wiring diagram


1.7 System Wiring

• Below shows the loop that Cerberus ECO FC18/FC18R controllers connect with a line card FCI1801.



2.1 FR18-BUS

Communication between FT1810 floor repeater display and FC18 controllers (CAN-BUS communication). The maximum length is 1,000m.

2.2 FR18-BUS Floor Repeater Display (FRT) wiring diagram

- Note: Ensure positive and negative connections properly in place, FC18-Bus polarity-sensitive.
- FR18-BUS network will need to install end of line resistor (120Ω) at both ends (EOL setting via dip-switch or jumper).



3.1 FD18-BUS

Communication between line cards and field devices. The wiring length should less than 1,500m for stub structure and 2,500m for loop structure.

3.2 FD18-BUS Line card diagram

Note: In loop mode, wires from BP1 must end at AP1; wires from BS1 must end at AS1. Connection of field devices polarity-free.



3.3 FD18-BUS Detection loop topology

Detection loop topology for FS18 fire alarm control system:

3.3.1 Loop Topology



Stub on Loop Topology

3.3.2 Stub Topology

3.3.3 Stub on loop topology

3.3.4 Line Separator application A

- Maximum 32 FD181 field devices can be connected to line separator or between two line separator.
- One node cannot be connected by three or more line separators in the same detection line. (The topologies of Fig. 3.3.7 to Fig. 3.3.9 are not supported).
- The line resistance between the controller and the nearest line separator or between two line separators shall be less than 17.5Ω , otherwise line separators are not guaranteed to work normally.



3.3.5 Line Separator application B



3.3.6 Line Separator application C



3.3.7 Line Separator application D



3.3.8 Line Separator application E



3.3.9 Line Separator application F



4.1 FDB181/FDB183 Detector Base Installation

The installation of a base should strictly follow the engineering design drawings, with bases should be evenly distributed.

Procedure of installation:

- 1. Insert the cables through the base and connect them to the terminals.
- 2. Fix the base to the ceiling with screws.

Note:

- The detector should be installed once construction has been finished.
- In order to ensure the reliability of the connection between the base and the detector, please do not use U-type terminals.
- Twisted-pairs with the wiring requirement of 1.0~1.5mm² are recommended.

4.2 FDB181C Collective Detector Base Installation

The installation of a base should strictly follow the engineering design drawings. The bases should be evenly distributed.



Procedure of installation:

- 1. Insert the cables through the base and connect them to the terminals.
- 2. Fix the base to the ceiling with screws.

Note:

- The detector should be installed after the construction has been finished.
- In order to ensure the reliability of the connection between the base and the detector, please do not use U-type terminals.
- Twisted-pairs with the wiring requirement of 1.0~1.5mm² are recommended.



4.3 FDCAI181 Addressable Alarm Indicator Installation



Installation of FDCAI181:

- 1. Remove the white cover cap (press the black cam).
- Mount the base plate (Fig. 2) on a wall or recessmounted socket using 2 ... 4 screws with max. diameter 3 mm.
- 3. Connect the alarm indicator in accordance with the connection diagram (Fig. 5).
- 4. Refit the white cover cap.
- 5. Snap the white cover cap into place.

Installation of additional frame AI330:

- For surface-mounted cable entry the additional frame AI330 must also be mounted.
- Max. cable diameter: 10 mm
- 1. Mount the additional frame AI330 (accessory) on a wall or recess-mounted socket using two screws with max. diameter of 4 mm (Fig. 3, Fig. 4).
- 2. Remove the white cover cap from alarm indicator FDCAI181 (press the black cam).
- 3. Attach the base plate of the alarm indicator to additional frame AI330 with 2 wood or sheet-metal screws of di-ameter 3 mm, max. 16 mm long.
- 4. Connect the alarm indicator in accordance with the connection diagram (Fig. 5).
- 5. Refit the white cover cap.
- 6. Snap the white cover cap into place.



Details for ordering

Туре	Part No.	Designation	Weight
FDCAI181	S54370-F21-A1	Addressable alarm	0.0493 kg
		indicator	

4.4 FDCL181 Line Separator Installation



Preparation

Determine the type of installation: there are 2 types of installation for FDCL181 line separator:

- Installation outside a switching cabinet or a control unit: use FDCH221 housing (Fig. 4.3.2) .
- Installation directly in a switching cabinet or a control unit: mount the module on an even surface (Fig.4.3.1).

Damage by water!

In humid or wet environments always use the housing FDCH221!

Installation of FDCH221 Housing

- 1. Open the housing.
- 2. Determine the cable entries in the housing and break these open.
- 3. Use two screws (M4) to fit the housing on a plane surface (Fig. 4.3.2). Distance between holes: 182.0±1.0mm.
- 4. Fix and guide in the cables with waterproof joint (provided by installers).
- 5. Fix the lid additionally with four screws (Fig. 4.3.3). (Only this way is IP protection guaranteed.



Installation of module in FDCH221

- Caution! Overheating of FDCL81line separator.
- 1. Open the housing.
- 2. Fix module with two screws in the housing (Fig. 4.3.2).
- 3. Press the module until it fits the housing.

Installation on an flat surface

- 1. Position module on an flat surface.
- 2. Fix module with two screws M4x15 (Fig. 4.3.1).
- Distance between holes: 63.5±1.0mm.

Electric connection

1. Connect the cables to the terminals according to Fig. 4.3.4.

4.5 Installation of FDCI181-2 Input Module



Fig. 6

Fig. 5

Preparation

Determine the type of installation: there are 2 types of installation for FDCI181-2 Input module:

- Installation outside a switching cabinet or a control unit: use FDCH221 housing (Fig. 3).
- Installation directly in a switching cabinet or a control unit: mount the module on an even surface (Fig.2).



Damage by water!

In humid or wet environments always use the housing FDCH221!

Installation of FDCH221 Housing

- 1. Open the housing.
- 2. Determine the cable entries in the housing and break these open.
- 3. Use two screws (M 4) to fit the housing on a plane surface (Fig. 3). Distance between holes: 182.0±1.0mm.
- 4. Fix and guide in the cables with waterproof joint (provided by users themselves).
- 5. Fix the lid additionally with four screws (Fig. 4). (Only this way is IP65 protection guaranteed.)

lation position to make sure that the LEDs of the module are visible at any time.

Installation of module in FDCH221 housing



Caution! Overheating of FDCI181-2 input module.

- 1. Open the housing.
- 2. Fix module with two screws in the housing (Fig. 3).
- 3. Close the housing.

Installation on an even surface

- 1. Position module on an even surface (Fig. 2).
- 2. Fix module with two M4 screws. Distance between holes:63.5±1.0mm.

Electric connection

1. Connect the cables to the terminals according to Fig. 5/6.



Connect only one wire per terminal!

The housing lid is transparent. Consider a suitable instal- 2. Connect the resistors to the end of the monitored line. 2 resistors of $3.3K\Omega$ and 2 of 680Ω are delivered with the product.

4.6 FDCIO181-2 Input/Output Module Installation



Determine type of installation:

- Installation outside a switching cabinet or a control unit: use FDCH221 housing (Fig. 4.5.2).
- Installation directly in a switching cabinet or a control unit: mount the module on an even surface (Fig. 4.5.1).

Damage by water!

In humid or wet environments always use FDCH221 housing!

Installation of FDCH221 Housing

- 1. Open the housing.
- 2. Determine the position of the cable entries in the housing and break them out.
- 3. Mount the housing on an even surface with two screws (Fig. 4.5.2). Distance between holes: 182.0±1.0mm.
- 4. Insert the cables and fix the cables in the housing.
- 5. Insert the seal and fix the lid additionally with four screws (Fig. 4.5.3) (only this way is IP65 protection guaranteed).

The housing lid is transparent. Consider suitable installation position to ensure module LEDs visible at any time.

© Siemens Limited. Building Technologies Division

Caution! Overheat

Overheating of FDCIO181-2 input/output module.

- 1. Open the housing.
- 2. Place the module in the housing and fix it with two screws (Fig. 9/10).
- 3. Close the housing.

Procedure with installation on an flat surface

- 1. Place the module on an even surface.
- 2. Fix the module with two screws (M4x15) (Fig. 4.5.1). Distance between holes: 63.5±1.0mm

Electric connection

- 1. Referring to Figures connect the cables to the corresponding terminals.
- 2. Connect resistor/ diode .The resistors must be connected at the end of the monitored line.
- 3. Fix the cables to the module



Mind the positive and negative polar when connecting the diodes.

4.7 FDCI183 Collective Input Module Installation



- 2. Connect the line terminators (EOL). These must be connected to the end of the line (Fig. 4.6.7 /Fig. 4.6.8).
- 3. Connect the cables to the module with cable ties (max. width 2.6 mm).

4.8 FDCIO181-1 Input/Output Module Installation





Fig. 4.7.4

Preparation

- 1. Determine type of installation:
- Installation outside a switching cabinet or a control unit: use FDCH221 housing (Fig. 10).
- Installation directly in a switching cabinet or a control unit: mount the module on an even surface (Fig. 9).

\triangle

Damage by water!

In humid or wet environments always use FDCH221 housing!

Mounting FDCH221 housing

- 1. Open the housing.
- 2. Determine the position of the cable entries in the housing and break them out.
- 3. Mount the housing on an even surface with two screws (Fig. 10). Distance between holes: 182.0±1.0mm.
- 4. Insert the cables and fix the cables in the housing.
- 5. Insert the seal and fix the lid additionally with four screws (Fig. 11) (only this way is IP65 protection guaranteed).



The housing lid is transparent. Consider a suitable instal-lation position to make sure that the LEDs of the module are visible at any time.

Procedure with installation in the housing

0

Fig. 4.7.3



Fig. 4.7.2

Overheating of the input/output module!

1. Open the housing.

CAUTION

- 2. Place the module in the housing and fix it with two screws (Fig. 9/10).
- 3. Close the housing.

Procedure with installation on an even surface

- 1. Place the module on an even surface.
- 2. Fix the module with two screws (M4 X15) (Fig. 9). Distance between holes: 63.5±1.0mm

Electric connection

- 1. Referring to Fig. 1,3,5,7,12 connect the cables to the corresponding terminals.
- 2. Connect resistor/ diode .The resistors must be connected at the end of the monitored line.
- 3. Fix the cables to the module

CAUTION

Mind the positive and negative polar when connecting the diodes.

4.9 FDCI181-1 Input Module Installation







Fig. 4.8.3

Fig. 4.8.4



Fig. 4.8.2

Fig. 4.8.5

Preparation

Determine the type of installation: there are 2 types of installation for FDCI181-1 Input module:

- Installation outside a switching cabinet or a control unit: use FDCH221 housing (Fig. 3).
- Installation directly in a switching cabinet or a control unit: mount the module on an even surface (Fig.2).



Damage by water!

In humid or wet environments always use the housing FDCH221!

Installation of FDCH221 Housing

- 1. Open the housing.
- 2. Determine the cable entries in the housing and break these open.
- 3. Use two screws (M 4) to fit the housing on a plane surface (Fig. 3). Distance between holes: 182.0±1.0mm.
- 4. Fix and guide in the cables with waterproof joint (provided by users themselves).
- 5. Fix the lid additionally with four screws (Fig. 4). (Only this way is IP65 protection guaranteed.)



The housing lid is transparent. Consider a suitable instal-lation position to make sure that the LEDs of the module are visible at any time.

Installation of module in FDCH221 housing

Caution! Overheating of FDCI81-1 input module.

- 1. Open the housing.
- 2. Fix module with two screws in the housing (Fig. 3).
- 3. Close the housing.

Installation on an even surface

- 1. Position module on an even surface (Fig. 2).
- 2. Fix module with two M4 screws. Distance between holes:63.5±1.0mm.

Electric connection

1. Connect the cables to the terminals according to Fig. 5/6.



Connect only one wire per terminal!

2. Connect the resistors to the end of the monitored line. 1 resistors of $3.3K\Omega$ and 1 of 680Ω are delivered with the product.

4.10 FDM181 Manual Call Point Installation





(1/3 - housing; 2 - electronic component)

Fig. 4.9.2 Exploded view

Fig. 4.9.1

Preparation

- Remove key, open the housing.(Fig. 4.7.1) Keep the key in a safe place.
- Fix the housing.
- Drill the inlet opening (Break the joint between the opening and the housing with a screwdriver)



Risk of injury!

Observe the tool manufacturer's safety notes!

Installation

- 1. Fix the housing at a height of 1.3 to 1.5 m on an flat surface.
- 2. Pull the cables through the inlet opening(s) and into the housing.
- 3. Close the housing with the cover.



Electrical connection

- 1. Open cover with key (see Fig. 4.7.1).
- 2. Connect the feed line to the terminals on the electronic component according to the connection diagram (see Fig. 4.7.3).
- 3. Place electronic component into housing marked "TOP" pointing upward (terminals at right) until locking device engages (see Fig. 4.7.2).
- 4. Close the housing with the cover.

Pay attention to the cables when placing the electronic component into the housing!

4.11 FT1810 Floor Repeater Display Installation



Installation

- 1. Insert the loop line and external power wire through the floor repeater display.
- 2. Mark the drillings for the 3 dowel openings on a flat wall, drill the holes, put expansion bolts in and insert the screws loosely (Fig. 4.8.1).
- 3. Hang the floor repeater display on those screws through the waist-shape holes.
- 4. Open the front panel (Fig. 4.8.3/4.8.4), (make sure the bolt is on the open position) and tighten the screws.
- 5. Connect the cables to the terminal in accordance with the connection diagram (Fig. 4.8.2). The terminal equipment of FR18-BUS is required to be parallel connected with a resistance of 120Ω , which can be achieved through internal jumper of FT1810.
- 6. Close the front panel.
- 7. Lock it with the key. Remove the key and put it away.

4.12 FTM1811 Mimic Display Board Installation



Fig. 4.11.4 Connection diagram 1

Procedure

- 1. Define the place of installation:
 - Outside an electric cabinet or controller (indoor only)
 In an electric cabinet or in controller
- 2. Use four screws to fix the metal board of FTM1811 in controller/electric cabinet or on the wall z(refer to Fig.4.9.1/Fig.4.9.2).
- 3. Install PCB board on the metal board (refer to Fig. 4.9.3).
- 4. Connect the cables to the terminals (refer to Fig. 4.9.4./Fig.4.9.5)
- 5. Connect the jumper depending on if the FTM1811 is placed the end of FR18-BUS(CAN-Bus) line.

Note: Wiring capacity of power supply should be more than 1.5 mm².

Siemens Switzerland Ltd Infrastructure & Cities Sector Building Technologies Division International Headquarters Gubelstrasse 22 6301 Zug Switzerland Tel +41 41 724 24 24

The information in this document contains general descriptions of technical options available, which do not always have to be present in individual cases. The required features should therefore be specified in each individual case at the time of closing the contract.

© Siemens Switzerland Ltd

Answers for infrastructure.

Our world is undergoing changes that force us to think in new ways: demographic change, urbanization, global warming and resource shortages. Maximum efficiency has top priority – and not only where energy is concerned. In addition, we need to increase comfort for the well-being of users. Also, our need for safety and security is constantly growing. For our customers, success is defined by how well they manage these challenges. Siemens has the answers.

"We are the preferred partner for energy-efficient, safe and secure buildings and infrastructure."